




COOKTOP PARTS

For Model: SF111PXSQ1

(Designer White)

30" GAS FREESTANDING
STANDARD CLEAN RANGE
ELECTRONIC IGNITION



Illus. No.	Part No.	DESCRIPTION
1	W10032070	Literature Parts
	98015589	Instructions
	98015589	Installation
	98015589	Installation Instr (Template)
	W10106860	Guide, Use & Care
	98007130	Safer Cooking Tips
	98007032	Tech Sheet

Illus. No.	Part No.	DESCRIPTION
2	98017619W	Cooktop
3	W10094870	Panel, Manifold
4	98006102	Knob, Burner (4)
5	98007225	Screw
6	98013747	Grate, Burner (2)
7	98004722	Clip, Cooktop (2)
8	98014544	Wire, Ground


Illus. No.	Part No.	DESCRIPTION
9	98013389	Bumper, Cooktop
10	98005000	Screw (3)
11	98017465	Cap, Burner (4)
12	8534079	Screw
13	98008321	Knob, Oven
14	98017537	Burner, Top (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BACKGUARD PARTS

For Model: SF111PXSQ1

(Designer White)




Illus. No.	Part No.	DESCRIPTION
1	98005336	Endcap White Left
	98005337	White Right
2	98006083	Rear, Backguard
3	98006393	Swtich, Rocker
4	98017735W	Panel, Backguard
5	9757609	Nameplate
7	98015526	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Model: SF111PXSQ1

(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Model: SF111PXSQ1

(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	98017323	Nut (4)
2	98017582	Venturi, Front (2)
3	98017741	Brkt., Venturi (4)
4	98017359	Venturi, Rear (2)
5	6610341	Spark Module
6	98007411	Regulator
7	98007192	Cover, Module
8	98015099	Spreader, Flame
9	98006632	Screw
10	98012138	Burner, Oven
11	98006633	Screw
12	98017409	Harness, Switch
13	98014893	Valve, Oven
14	98006633	Screw
15	98017498	Valve, Burner (4)
16	98017517	Bolt, Valve Mtg
17	98017558	Pipe, Manifold

Illus. No.	Part No.	DESCRIPTION
18	98009179	U-Nut
19	98003984	Thermostat, Oven
	98005663	Bolt, T-Stat Mtg
20	98017348	Orifice (4)
21	98005652	Igniter, Oven Oven Pilot)
22	98017516	Bracket, Valve (4)
23	98007428	Tubing (Regltr to Oven Valve)
24	98013314	Locator, Burner
25	98007410	Bracket, Regulator
26	98007431	Fitting 3/8to9/16
27	98013634	Screw
28	1180823	Screw
31	98017171	Tubing, Inlet

Illus. No.	Part No.	DESCRIPTION
34	98005659	Screw
35	98004484	Screw
36		Igniter, Top
	98017562	LF
	98017561	RR & RF
	98017563	LR
37	98015032	Clip, Igniter

FOLLOWING PARTS NOT ILLUSTRATED


W10032010 LP Spud Kit
(For Use With LP)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Model: SF111PXSQ1

(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Model: SF111PXSQ1

(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	98003799	Flue Box
2	98013690	Clip, Flue
3	98014398	Shield, Insulation
4	98010042	Panel, Side (2)
5	98005502	Clip, Oven Bottom
6	98006710	Counterweight
7	98006739	Wire, Brick
8	98006750	Frame, Front
9	98005306	Foot, Front (2)
10	9761935	Foot, Rear (2)
11	98004449	Bottom, Oven
12	98015683	Baffle, Side (2)
13	98003847	Baffle, Base
14	98003830	Rail, Base (2)
15	98012175	Support, Burner
16	98005642	Clip, Bulb (2)
18	98009179	U-Nut
20	98015100	Back, Main
21	98017163	Seal, Oven
22	98006633	Screw
23	98007193	Washer
24	98007126	Base, Foot
25	98006632	Screw
26	98006715	Shield, Channel
27	98007191	Shield, Lower
29	98014532	Cord, Power
30	98005026	Clip, Tubing
31	98015346	Foil, Side (2)
32	98006634	Screw
33	98004447	Top, Oven
34		Side, Oven
	98004452	Right Hand
	98004451	Left Hand
35	98013777	Back, Oven
36	98015363	Support, Rear
37	98004498	Bulb, Light
38	98004293	Socket, Light
39	98008545	Screw (4)
40	98007205	Cap, Insulation
42	98014105	Cover, Valve
43	98014104	Cover, Socket


INSULATION

98014360 Insulation, Wrap
98004286 Insulation, Back

OVEN & BROILER PARTS

For Model: SF111PXSQ1

(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	98014136	Rack, Oven (2)
2	98003480	Grill, Broiler
3	98016005	Pan, Broiler
4	98016570	Rack, Broiler
5	98004761	Bracket, Rack (2)
6	98004715	Guide, Rack(4)
7	98003790	Hanger, Brlr Door
8	98006727	Screw
9	98004698	Liner, Door

Illus. No.	Part No.	DESCRIPTION
11	98015234	Insulation, Door
12	98009337	Panel, Door
13	98006623	Handle, Brlr Door
14	98004773	Spacer, Handle
15	98004052	Bumper, Door(2)
16	98006644	Screw
17	98006633	Screw
18	98003791	Support, Hinge


Illus. No.	Part No.	DESCRIPTION
19		Spring, Broiler
	98008380	Right
	98008379	Left
20	98004219	Screw
21	98007396	Spacer, Hinge
22	98004053	Pin, Hinge (2)
23	98008341	Cover, Guide(4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Model: SF111PXSQ1

(Designer White)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	8533842	Screw
3	98010182	Liner, Door
4	98006753	Insulation, Door
5		Clip, Glass
	98004952	Left
	98004953	Right
6	98017875	Hinge, Door (2)
7	98017767W	Trim, Top Door
8	98017961W	Panel, Door
9	98006801	Glass, Inner (2)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

10	98017790W	Handle, Oven Door
11	98010557	Actuator (2)
12	98004993	Screw
13		Side Trim, Door(2)
	98016787W	White Left
	98016795W	White Right
14	98008544	Screw
15		Retainer
	98004564	Right
	98004629	Left

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

16	98010185	Lower Trim, Door
17	98004219	Screw
18	98004227	Bumper
19	98004938	Insulation, Retainer-Top
20	98012904	Insulation, Retainer-Bottom
21	98017250	Retainer, Upper

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Model: SF111PXSQ1

(Designer White)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Following Parts Not Illustrated

SPLICING WIRES--25FT. LENGTH

242828	Wire, Black	12 Ga. 150° c
8316781	Wire, Black	14 Ga. 150°c
242821	Wire, Blue	14 Ga. 150°c
242822	Wire, Brown	14 Ga. 150°c
242830	Wire, Brown	14 Ga. 200°c
242823	Wire, Green	14 Ga. 150°c
242824	Wire, Orange	14 Ga. 150°c
242825	Wire, Red	14 Ga. 150°c
242831	Wire, Red	14 Ga. 200°c
242827	Wire, Yellow	14 Ga. 150°c

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch-Up Self-Clean(1/2 Pt)
261582	Grease

INSULATION

261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
240132	Insulation, Fiberglass (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2oz.)

72017	White
4392899	Biscuit
511873	White Porcelain (2 Oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

WIRING HARNESS PARTS

6610437	Harness, Control
98005896	Clip, Wire
3196696	Clip, Wire
3391018	Cable Tie-Push Mnt
98015022	Bushing, Snap (2)
98005894	Clamp, Cord

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit(Uncut)

ANTI-TIP KIT

98017833	Anti-Tip Kit
----------	--------------

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST